

CORRECT SETTING OF OSCILLATING KNIFE

There are two possible ways to set the oscillating knife and only one of them is correct.

Pleasepay attention to the differences:

CORRECT POSITIONING



WRONG POSITIONING



You can verify the position of the knife using a caliper in the way shown in the picture below. The correct height of the knife and the toolholder is 53mm

